

LED LIGHT BAR

INSTRUCTION MANUAL





THANK YOU FOR PURCHASING OUR MIRADOR LED LIGHT BAR !

This manual will provide you with clear and detailed instructions on how to safely and correctly assemble and maintain your product, to ensure it brings you many years of use and enjoyment.

IMPORTANT: RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

Warning: Important safety instructions. It is important for the safety of persons to follow these instructions. Please keep these instructions in a safe place.

Any use or modification to the product not included in this manual shall be considered as improper use, which may cause considerable danger to users and property and will void the product warranty.

Please only use this product for its intended purpose within a residential environment. Failure to do so will void your warranty.

We reserve the right to make changes for product improvements.

For parts and customer service, please call +1 (877)-506-4777 in the U.S. and Canada (English and Spanish)
Monday - Friday: 5:00 am - 11:00 pm, Saturday - Sunday: 8:30 am - 4:30 pm, Pacific Time. For other regions, email: support@miradoroutdoor.com

Digital instruction manual is also available on our official website **www.miradoroutdoor.com/pages/help-center** for your reference.

TABLE OF CONTENTS

04 Before Assembly

05 Important Safety Advice

08 Technical Data & List of Parts

09 Assembly

15 Care & Maintenance

16 Warranty & Complaints Procedure

17 Disassembly & Disposal of The Product

BEFORE ASSEMBLY

WARNING: Important safety instructions. Follow all instructions, since incorrect assembly can lead to severe injury.

Make sure you have all the tools required for assembling your product:

In order to assemble your product safely and correctly, please ensure you have access to the following tools and accessories, all of which are not provided.



Check to ensure there are no missing parts:

Before you begin assembly, please check that you have all the parts required to assemble your product. Please also carefully check that the quantity of parts matches with that of the model you have purchased.

If any parts are missing, please refer to the **Warranty & Complaints Procedure** to contact customer service before beginning the assembly.

Prepare the parts you will need for each step:

In the **Assembly** section of the manual, each step indicates the necessary parts and quantities required to complete the step. We recommend that you prepare the parts you will need for each assembly step. Doing this will save you time and effort during assembly. If possible, place the parts on cardboard or other soft surface to protect from scratching the painted surfaces.

Select a suitable location:

- Easy access to power.
- No overhanging trees and powerlines.
- For use with a pergola, the product must be positioned and fixed on a properly installed pergola, which is installed on a flat concrete ground, providing proper stability.
- For other applications, the product must be installed on a solid, level, and structurally sound surface to ensure safe installation and operation.

Warning:

If the product is installed on an uneven surface, it may prevent accessory components from working correctly and may void the product warranty.

IMPORTANT SAFETY ADVICE

For the safety of all persons assembling and using the product, it is important to follow the safety guidelines below.

PREPARATION



Work well away from power lines, particularly when handling metal parts.



Wear work shoes, gloves, and eye protection where appropriate.



Keep children and pets away from the work area - small parts, tools, and packaging can pose choking or injury risks.



Do not attempt to assemble the product in windy or wet conditions.



Make sure all electrical connections are disconnected from the mains during assembly.



Recycle packaging and dispose of plastic bags safely, out of children's reach.

DURING USAGE



Only use the power supply provided by Mirador.



Hot items such as recently used grills, blowtorches, etc. must not be placed under or near the product or its power cord.



Do not pull on or apply excessive force to the cord connection.



Do not hang from the product or place any objects on it.



Any modification to the product could compromise its structural integrity and will void your warranty.



Electrical Installation may only be carried out by certified personnel according to the applicable regulation (e.g. VDE 100 for Europe).



Do not allow children to operate the remote controls. Keep them away from children.



The product should only be connected to power sources that have been installed by a licensed electrical contractor.



Prior to each operation, visually inspect the product for damage. If any damage is found, stop using the product immediately and contact the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

WARNING

When using the product, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury, including the following:



Do not use the product in any manner that may damage the outer jacket or cord insulation.



Risk of Electric Shock. Do not use with extension cord near water or where water may accumulate.




Risk of Fire and Electric Shock. Do not install near flammable liquids.



The power plug must be connected to an indoor electrical outlet only.



Material may become brittle when cold. Do not install where it may be stepped on or subject to physical damage.



For use only on GFCI protected circuits.



Suitable for outdoor use.

TECHNICAL DATA

Light LED Strip	Input Voltage	24V DC
	Maximum Power	12W/M
	Ingress Protection Rating	IP45

LIST OF PARTS

*Extra spare parts included


A

x1



Z1

x4+2*



Z2

x0+2*






X

x2



ASSEMBLY


— Fit Range




01

A x1 

X 









02



Notice:







Use holes 1 & 3 for pergola; for other scenarios, choose holes as needed. Avoid pinching wires.







04

Z1 x 4





CARE & MAINTENANCE




Regularly check that all bolts and fittings are secure. Tighten if needed.



Do not use any bleach, ammonia, acidic, alkaline or other caustic cleaners.



Use only manufacturer-approved replacement parts.



In case of extreme weather conditions, disassemble the product and store it properly.



Turn off the power before cleaning.



Disconnect the cables if the product is not being used for long periods.



Wipe the surface gently with a soft, dry cloth.



When the temperature is below 0°C/32°F, it is recommended to use the product less frequently to prolong the product's service life.



Regular cleaning helps maintain brightness and extend product lifespan.

PERIODIC INSPECTION

Frequently examine the assembly for imbalance and signs of wear or damage to cables and springs.

- Do not use if repair or adjustment is necessary.
- Check the condition of the electrical cables and inspect their mains connection.

WARRANTY & COMPLAINTS PROCEDURE

For terms and conditions of our limited warranty, please visit : www.miradoroutdoor.com/pages/warranty or contact your local Mirador sales representative.

Complaints procedure:

- The complaint must include an order number or transaction number. Goods without an order number or transaction number are not covered under the warranty.
- The complaint must include a detailed description of the defect, the name of the company which assembled the product if a 3rd party was used and the date when the defect was discovered.
- Customer must offer supplier the photos/videos of the issue/damaged parts. Otherwise, supplier reserves the right to refuse replacement parts or credit.
- Please save a copy of your purchase receipt.

Contact:

Phone

+1 (877)-506-4777

Operation hours: Monday - Friday: 5:00 am - 11:00 pm, Saturday – Sunday: 8:30 am – 4:30 pm, PST.

Language: English and Spanish

E-mail

support@miradoroutdoor.com

Operation hours: We are available 24 hours a day. Please allow up to 24 hours for a response.

Language: English, Spanish and Canadian French

Online

miradoroutdoor.com

Operation hours: Monday - Friday: 5:00 am - 11:00 pm, Saturday – Sunday: 8:30 am – 4:30 pm, PST.

Language: English, Spanish and Canadian French

Note: Our team is available to assist you during these hours. If you have any inquiries or require support outside of these hours, please leave a voicemail, send an email, or use our online contact form. We will get back to you promptly during the next available support hours. Thank you for choosing Mirador Outdoor!

DISASSEMBLY & DISPOSAL OF THE PRODUCT

Incorrect disassembly of the product may lead to serious injury and product damage.

Disassembly should be assigned to qualified personnel with adequate training within the scope of occupational health and safety and knowledge within the scope of recycling.

Disposal of used Electrical and Electronic Equipment

When the service life of the product is over, it is necessary to disassemble it for disposal and to sort the individual materials and components in compliance with the local regulations of your country.

Important disposal information

In compliance with European Directive 2012/19EU on waste electrical and electronic equipment (WEEE) it is forbidden to place the waste equipment marked with the crossed bin symbol with other waste to a container intended for domestic waste. Users wishing to dispose of electronic or electrical equipment are obliged to return it to a designated waste equipment collection point.

The above statutory obligations were introduced in order to limit the amount of waste generated from waste electrical and electronic equipment, and to ensure an appropriate level of collection, recovery and recycling. The equipment does not contain hazardous components which have a particularly adverse effect on the environment or human health.



Utilization of used batteries

In compliance with the provisions of the Directive 2006/66/EC of the European Parliament and of the Council of 6 September 2006 on batteries and accumulators and waste batteries and accumulators and repealing Directive 91/157/EEC, the End User is obliged to transfer used portable batteries, which are no longer used as a source of energy, to an official collection point. It is forbidden to place used batteries with other waste in the same container. To prevent environmental pollution and causing a possible hazard for human and animal health, used batteries should be disposed of in the correct container at the designated collection points.

more to
enjoy

FOLLOW US ON
WWW.MIRADOROUTDOOR.COM

 @miradoroutdoor  @MiradorOutdoor
 @miradoroutdoor  @miradoroutdoor

